



5-02	Mag. Cover	1
5-03	BB Follower	1
5-04	BB Guide	1
5-05	Mag. Base	1
5-06	Mag. Spring	1
5-07	BB Guide Spring	1
5-08	Spring Bar	1
7	Valve Combination	1
7-01	Valve Ring	1

1-01	Frame(L)	1	1-15	Spring Bar	1	1-31	Heavy Weight	1	3A-01	Barrel Seat(L)	1	7-02	Valve Seal	1
1-02	Frame(R)	1	1-16	Screw	7	1-32	Heavy Weight	1	3A-02	Barrel Seat(R)	1	7-03	Piercer Seal	1
1-03	Grip	1	1-19	Recoil Spring	1	1A	Trigger Combination	1	3A-03	Ejector(L)	1	7A-04	Valve Chamber	1
1-04	Mag. Catch	1	1-20	BB Stopper Spring	1	1-05	Trigger	1	3A-04	Ejector(R)	1	7A-05	Valve Cover	1
1-08	Safety	1	1-21	Fixing Guide Spring	1	1-06		1	3-05	Ejector Spring	1	7-06	Valve Spring	1
1-09	Safety Parts	1	1-22	Trigger Spring	1	1-07	Trigger Connector	1	3-06	Internal Barrel	1	7-07	Valve	1
1-10	Safety Spring Seat	1	1-23	Safety Spring	1	1-28	Spring Bar	2	3-08	Screw	2	7-08	Copper Ring	1
1A-11	Recoil Spring Stopper	1	1-24	Mag. Catch Spring	1	2	Slide Combination	1	3-09	C Washer	1	7-09	Filter	1
1A-12	Fixing Guide	1	1-25	Attacked Block	1	2-01	Slide	1	3-11	Screw	1	7-10	Piercer	1
1A-13	BB Housing	1	1A-26	BB Stopper	1	1-35	U Type Fiber Optic	1	311-5	Mag. Combination	1	7-11	Fixing Ring	1
1-14	Axis	1	1-30	Heavy Weight(Front)	1	3	Internal Barrel Combination	1	5-01	Mag. Body	1	8A	Knob Combination	1