



LOADING MAGAZINE






• PUSH DOWN BB INTO MAGAZINE



LOADING OPREATION & LOAD INDICATOR






- HOLD THE HANDLE AND PULL ALL THE WAY BACK UNTIL IT STOPS (LOAD INDICATOR POP OUT)
- PUSH FORWARD THE SPRING BOLT TO ITS ORIGINAL POSITION
- PULL THE COCKING HANDLE BACK DOWN


SWITCH FIRE MODE

SAFE MODE:

- FLIP SWITCH TOWARD THE REAR
- FIRE MODE:
- FLIP SWITCH TOWARD
 THE FRONT




TO SHOOT




THOP-UP ADJUSTMENT

- USE A HEX KEY TO ADJUST HOP-UP
- DAIL CLOCKWISE FOR MORE HOP-UP
- DAIL COUNTER-CLOCKWISE FOR LESS HOP-UP (HEX KEYS ARE INCLUDED INSIDE PISTOL GRIP)




REVERSE SLING LOOP POSITION



AMOEBA "STRIKER" S2 AIRSOFT SNIPER RIFLE

© AMOEBA AIRSOFT 2016. ALL RIGHTS RESERVED



■ SAFETY INSTRUCTIONS

SAFETY CONSIDERATIONS









Divisions of Forever Good (Hong Kong) Ltd.















ARES@ARESAIRSOFT.COM WWW.AMOEBA-AIRSOFT.COM WWW.ARESAIRSOFT.COM **F** AIRSOFTAMOEBA

